

Bracelet link calculator

Enter measurements in mm. Links to remove are split between both sides of the clasp.

Watch	Bracelet inner length	Wrist	Fit allowance	Link length	Links to remove	Side A	Side B
Example steel watch	200	170	10	7	2	1	1